G4121 Ambience
ADDENDA TO SECTION 7. LOG LAYOUT INSTRUCTIONS
(SUPERSEDES ISSUE 3 MANUAL) JAN-04

NOTE – USE THIS ADDENDA IN PLACE OF PUBLISHED DETAILS IN INSTRUCTIONS. KEEP THIS SAFE WITH THE REST OF THE INSTRUCTIONS FOR FUTURE REFERENCE.

Open the hinged door on the appliance, which is secured by a 10mm nut, to access the logs. On no account should the appliance be operated whilst the door is open except for brief periods during maintenance. Do not lay the logs in any way other than that shown.

7.0 LOG LAYOUT (NATURAL GAS)

The base and front logs are fixed in position and should only need removing for servicing. The base log locates onto the burner and the front log is pushed to the extreme left hand side. Take the 2 loose logs* and position them as shown onto the cut outs on the base log, taking care to locate them correctly to ensure clean combustion. No additional logs should be added to the fire.
Note the pilot position on the right hand side of the burner.

7.1 LOG LAYOUT (LPG PROPANE)

The base and front logs are fitted similar to the Natural Gas fire. The base log locates onto the burner and the front log is pushed to the extreme left hand side as shown. Take the 2 loose logs* and position them as shown onto the cut outs on the base log, taking care to locate them correctly to ensure clean combustion. No additional logs should be added to the fire.
Note the pilot position on the right hand side of the burner.

*Note – The 2 top logs may be supplied glued in position and should not be removed or repositioned. If they become detached then they can be fitted as per the diagram but must on no account be discarded or fitted in any other way.

Always secure the door closed after laying the fuel effects.

Do not attempt to use any unit with broken or damaged glass.

Do not use the fire with broken logs.

Do not add any additional fuel elements to the fire.

Do not use similar looking parts from other appliances, use only genuine spare parts.

Do not use the appliance for burning waste.