



Morsø Badger 3112 & 3142 Baffle Fitting Procedure

1. The Badger 3112 & 3142 have a two piece baffle arrangement.
A. The upper baffle
B. The front access baffle



2. Insert the upper baffle with the flat surface uppermost.



3. Slide the baffle backward over the top of the tertiary air system



4. Ensure the baffle is located parallel to the top of the tertiary air system with its front edge touching the inside face of the stove top plate.



5. Insert the front access baffle diagonally through the door



6. Lift the access baffle over the vermiculite bricks one side at a time



7. Finally fully locate the access baffle along the front edge of the tertiary air system.

