Parts Information



Diagram No.	Part No.	Description
1	TB-03-10-00	Handle
2	TB-03-00-00A	Steel door
3	TB-07-00-00	Three sided trim
4	TB-07-00-04A	Fourth/Bottom side trim
5	S-4-310x400	Glass panel
6	TB-04-00-00	Fuel retainer
7	TB-05-00-00	Ashpan
8	TB-200	Cast Iron solid fuel grate
9	TB-02-80-00A	Steel wood grate top
10	TB-100A	Wood grate top removing tool
11	TB-02-11-05A	Primary air slider
12	TB-02-11-04A	Secondary/Tertiary air slider
13	TB-02-30-01A	Left hand vermiculite panel
14	TB-02-30-03A	Right hand vermiculite panel
15	TB-02-30-04A	Lower vermiculite baffle
16	TB-02-20-00A	Upper steel baffle
17	TB-02-06-02A	Bottom grate side bricks x 2
18	TB-02-06-01A	Bottom grate rear brick
19	TB-02-30-02A	Rear vermiculite panel
20	TB-01-00-00A	Outer convection box
21	TB-01-08-00	Steel flue collar