



Operating & Installation Manual

The Becton MK 3 Range of Gas Stoves



(Becton 7 MK 3 Gas Stove)








PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE











FOR USE IN COUNTRIES
GB & IE

Rev 11
Part No. AFS1125









SPARE PARTS

Part Description	Visual Aid (not to scale)	Bunny mk3 Part No.	Becton 7 mk3 Part No.
1. Becton 7 mk3 Coal Set		-	AFGS1075
1a. Becton Bunny mk3 Coal Set		AFGS1074	-
2. Co-pilot assembly		AFGS089	AFGS089
3. Elbow Injector		AFGS090	AFGS090
4. Gas Control Valve		AFGS091A	AFGS091
5. Magnetic Catch for mk3 Gas Fires.		AFGS1073	AFGS1073
6. Hinge Kit To Fit Either Door. Comprises 2 Hinges & 4 Fixings Per Set.		AFS047	AFS047

SPARE PARTS

Part Description	Visual Aid (not to scale)	Bunny mk3 Part No.	Becton 7 mk3 Part No.
7. Control Door Handle Assembly		AFGS1085	AFGS1085
8. Burner & Fixing		AFGS1076	AFGS1077
9. Pipe Set Complete With Connectors		AFGS080	AFGS080
10. Decorative Door Surround (Trim)		AFS094A	AFS095
11. Fire Door Assembly complete with Magnet Lock and Trim		AFGS1078	AFGS1079
12. Glass Replacement Kit with Gasket & Fixings.		AFGS1080	AFGS1081
13. Hotplate		AFGS064	AFGS010
14. Flue Outlet Spigot		AFGS1082	AFGS1083

SPARE PARTS

Part Description	Visual Aid (not to scale)	Bunny mk3 Part No.	Becton 7 mk3 Part No.
15. Becton 7 mk3 Lining Kit		-	AFGS1072
16. Large Ceramic Panel		AFGS093	AFGS093
17. Medium Ceramic Panel		AFGS094	AFGS094
18. Small Ceramic Panel		AFGS1084	AFGS1084
19. Gas Tap		AFGS025	AFGS025
20. Manual		AFS1125	AFS1125
21. Feet and Fixings		AFS1013	AFS1013
22. Arrow Fires Gauntlet Gloves		AFS997	AFS997