

Rochester 5kW

Multi-Fuel Stove, Model No. FCSSB5 (Chrome Door) & FCSSB5B (Black Door)
Installation and Operating Instructions

Read these Instructions and use only the recommended fuels

Leave this manual with the householder following installation

To find a qualified installer, fuel supplier or chimney sweep please contact :-

UK - The Solid Fuel Association

7 Swanwick Court

Alfreton Derbyshire DE55 7AS

Tel: (0845) 601 4406 www.solidfuel.co.uk R.O.I. - Irish Nationwide Fireplace Organisation 162 Capel Street

Dublin

Tel (01) 801 5959 www.fireplace.ie


This Flavel Rochester Stove may be used in smoke control areas when operated strictly in accordance with these instructions and with Soliftec Smoke Advice Sheet No. 1 (www.soliftec.com/smokeadvice.htm) when burning :

UK : Untreated wood logs or authorised smokeless fuels (exempted from s20 of the clean air act 1993)

ROI : Wood logs, smokeless fuels or peat briquettes, but not petroleum coke (Control of Atmospheric Pollution Regulations, 1970)

Section 9 - Spare Parts

IMPORTANT: Only genuine Flavel spare parts should be used with this stove and no unauthorised modifications to this stove are permitted.



Due to our policy of continual improvement and development the exact accuracy of illustrations and descriptions contained in this book cannot be guaranteed.

B-1003836 Issue 2

23rd November 2016



BFM Europe Ltd. Trentham Lakes Stoke-on-Trent Staffordshire ST4 4TJ

www.bfm-europe.com

Telephone - General Enquiries:

Telephone - Service :

(01782) 339000

(01782) 339008