



STOVE SPARES


LEFT HAND DOOR

Left Hand Door
(HH04/070)

Cross (Removable)
(HH04/071B)

Door Glass
(HH04/073)

Glass Gasket
(HH04/072)



Glass Clip
(HHR08/046)

Glass Clip Screw
FSJM05008SS

Slider (not shown)
(HH04/091)

Slider Knob
(HHR08/045)

RIGHT HAND DOOR

Right Hand Door
(HH04/069)


Cross (Removable)
(HH04/071A)

Door Knob
(HCR06/059)

Shaft
(HHR08/111)

Circlip
(FLRX07)

Catch
(HMS04/037)




Door Glass
(HH04/030)

Glass Gasket
(HH04/072)

Slider (not shown)
(HH04/091)

Slider Knob
(HHR08/045)

STOVE BODY ASSEMBLY – PART SECTION – MULTIFUEL



STOVE BODY ASSEMBLY – PART SECTION – WOOD

