



## STOVE SPARES


Only Hunter Stoves authorised spares should be used with this stove.

### RIGHT HAND DOOR

Right Hand Door  
(HHR06/081)

Door Glass (HH06/083)  
Glass Gasket (HH06/084)

Door Knob (HCR06/059)  
M8 Full Nut (FNFN08)  
Catch Shaft (HHR08/111)  
Circlip (FLRX07)  
M8 Full Nut (FNFN08)  
Catch (HMSS04/037)



Glass Clip (HHR08/046)  
Glass Clip Screw (FSJM05008SS)


Door Slider (HHR06/098)  
Slider Knob (HHR08/045)

### LEFT HAND DOOR

Left Hand Door  
(HHR06/080)


Door Glass (HH06/083)  
Glass Gasket (HH06/084)

Door Slider (HHR06/098)  
Slider Knob (HHR08/045)



Glass Clip (HHR08/046)  
Glass Clip Screw (M58CHS/SS)

**STOVE BODY ASSEMBLY - PART SECTION - MULTIFUEL**



**STOVE BODY ASSEMBLY - PART SECTION - WOOD**

