



## STOVE SPARES

Only Hunter Stoves authorised spares should be used with this appliance


### RIGHT HAND DOOR

Right Hand Door  
(HHR16/002)

Door Glass  
(HHR16/005)

Glass Gasket  
(HHR16/006)

Door Knob (HCR06/059)  
M8 Full Nut (FNFM08)  
Catch Shaft (HHR08/111)  
Circlip (FLRX07)  
M8 Full Nut (FNFM08)  
Catch (HMSS04/037)



Glass Clip (HHR08/046)  
Glass Clip Screw (FSJM05008SS)


Door Slider (HHR08/119)  
Slider Knob (HHR08/045)

### LEFT HAND DOOR

Left Hand Door  
(HHR16/001)

Door Glass  
(HHR16/005)


Glass Gasket  
(HHR16/006)



Glass Clip (HHR08/046)  
Glass Clip Screw (FSJM05008SS)

Door Slider (HHR08/119)  
Slider Knob (HHR08/045)

**STOVE BODY ASSEMBLY - PART SECTION - MULTIFUEL**



**STOVE BODY ASSEMBLY - PART SECTION - WOOD**

