



STOVE SPARES

Only Hunter Stoves authorised spares should be used with this stove.

SINGLE DOOR


Door
(HHR08/072)

Door Knob
(HCR06/059)

Door Washer
(FWFM08017)

Door Nut
(FNFM08Z)

Shaft & Catch
(HHR08/122)



Door Cover
(HHR08/073)

Door Glass
(HHR08/074)

Glass Gasket
(HHR08/075)

Glass Clips
(HHR08/046)

Glass Clip Screw
(FSJM05008SS)

Slider (not shown)
(CH08/003)

Slider Screw
(FSHM08050)


Slider Knob
(HHR08/045)

RIGHT HAND DOOR

Door Glass
(HHR08/082)

Glass Gasket
(HHR08/081)

Door Knob (HCR06/059)
M8 Full Nut (FNFN08)
Catch Shaft (HHR08/111)
Circlip (FLRX07)
M8 Full Nut (FNFN08)
Catch (HMSS04/037)



Right Hand Door
(HHR08/084)

Glass Clip
(HHR08/046)

Glass Clip Screw
(FSJM05008SS)

Door Slider (HHR08/119)
Slider Knob (HHR08/045)


LEFT HAND DOOR

Left Hand Door
(HHR08/079)

Door Glass
(HHR08/082)

Glass Gasket
(HHR08/081)

Door Slider (HHR08/022)
Slider Knob (HHR08/045)




Glass Clip
(HHR08/046)

Glass Clip Screw
(FSJM05008SS)

Door Slider (HHR08/119)
Slider Knob (HHR08/045)

BODY ASSEMBLY – PART SECTION - MULTIFUEL



BODY ASSEMBLY – PART SECTION – WOOD

