

Part list 2110

Pos.No.	Parts	2110 RIB UK
		64180921
1	Intermediate frame	44180600
2	Front grate	44180721
3	Inside rear plate	34184000
4	Side plate	44142921
5	Top plate	44180521
6	Inside top plate	44181100
7	Base plate	44185621
8	Baffle plate, cast iron	44181400
9	Rear plate, cast iron	44184521
10	Front frame	44180221
11	Door left	44180921
12	Door right	44181021
13	Screw	
14	Fitting w. thread for cover	44256800
15	Cover	44261021
16	Draft reducer	
17	Flue collar	44262721
18	Leg	44180321
19	Poker	541075
20	Hinge pin	541082
21	Distance tube	
22	Hinge pin	541808
23	Ash tray	54181400
24	Distance bush	54181700
25	Radiant shielding, bottom	
26	Convection rear plate	
27	Intermediate frame fitting	541830
28	Hinge pin	542056
29	Draught control	71180200
30	Draught control arm	71180300
31	Draught control frame	71180400
32	Baffle plate, stainless	
33	Black steel set screw	731608
34	Black steel set screw	731616
35	Black steel set screw	731620
36	Grate frame	44132200
37	Black steel set screw	731630
38	Black steel set screw	731635
39	Black steel set screw	
40	Black steel set screw	731825
41	Black steel set screw	731830
42	Screw	742508
43	Screw	743625
44	Screw	743635
45	Brass washer	746006
46	Handle	
47	Axis for handle	752627
48	Ceramic glass	790721
49	Riddling grate	44162500
50	Tightening tape	79074400
51	Stone	790920
52	Cotter pin	791870
53	Spring washer	79189700
54	Glass fitting	790743
55	Air slider washer	791891
56	Screw	
57	Screw	
58	Plate for intermediate frame	
59	Screw	742406
60	Hanging for handle	
61	Insulation	
62	Door handle	44181321
63	Inside side plate	752625
64	Black steel set screw	
65	Screw	
66	Fitting with thread for flue	
67	Shaking handle	44256700
68	Riddling arm	44262021
69	Distance tube	541807
70	steel box nut	
73	Riddling arm knob	
75	Bush	752619
76	Radiantplate - side	752621
77	Washer	
79	Axle	
80	Bush	
81	Spring shell	
82	Bush	
83	Brass nut	
84	Spring	
85	Spring	79048800
86	Washer	79189400
87	Screw	731625
88	Access Door	

		541833
		541827
		541828