



Ref. No.	Product Code	Description	Casting No.
REGENCY STOVES - Common to all Regency Stoves			
1	REG2	Blanking plate	11446-5
2	SBB	Small brass balls (pair)	
2	LBB	Large brass balls (pair)	
7	REG3	Leg	12615-5
11	REG8	Boiler blanking plate	
12	REG1	Flue adaptor/damper	14319
15	REG4	Draught adjuster	14137-5
16	REG5	Knob, draught adjuster, brass	14123-5
22	REG6	Door catch assembly	12875-5
23	BR48	Door pin	
REGENCY STOVE - small			
3	SR2	Top plate	11101-5
4	SR11	Side cheek, RH	12301-5
5	SR6	Door panel, RH outer	12859-5
6	SR13	Lip plate	12201-5
8	SR14	Door panel, LH outer	12860-5
9	SR1	Base plate	12205-5
10	SR10	Side cheek, LH	12305-5
13	SR12	Back plate	12401-5
14	SR5	Top front casting	12112-5
17	SR7	Door panel, RH inner	12823-5
18	SR15	Door panel, LH inner	12824-5
19	SR3	Ashpan	
20	SR9	Grate	10201-5
21	SR8	Baffle plate	15123-5
REGENCY STOVE - medium			
3	MR2	Top plate	11101-6
4	MR11	Side cheek, RH	12301-6
5	MR6	Door panel, RH outer	12859-6
6	MR13	Lip plate	12201-6
8	MR14	Door panel, LH outer	12860-6
9	MR1	Base plate	12205-6
10	MR10	Side cheek, LH	12305-6
13	MR12	Back plate	12401-6
14	MR5	Top front casting	12112-6
17	MR7	Door panel, RH inner	12823-6
18	MR15	Door panel, LH inner	12824-6
19	MR3	Ashpan	
20	MR9	Grate	10201-6
21	MR8	Baffle plate	15123-6

Ref. No.	Product Code	Description	Casting No.
REGENCY STOVE - large			
3	LR2	Top plate	11101-7
4	MR11	Side cheek, RH	12301-6
5	LR15	Door panel, RH outer	12824-7
6	LR13	Lip plate	12201-7
8	LR14	Door panel, LH outer	12860-7
9	LR1	Base plate	12205-7
10	MR10	Side cheek, LH	12305-6
13	LR12	Back plate	12401-7
14	LR5	Top front casting	12112-7
17	LR6	Door panel, RH inner	12859-7
18	LR7	Door panel, LH inner	12823-7
19	LR3	Ashpan	
20	LR9	Grate	10201-7
21	LR8	Baffle plate	15123-7

For common fixings, please see page 36
For Rope Seal packs, please see page 37